



Mounting- and Operating Instructions

ZMF-201e-IR

Methane Sensor



Fluid.iO Sensor + Control
GmbH & Co. KG
Hollandsmühle 1
98544 Zella-Mehlis

Tel.: +49 (0) 6251 84620
Fax: +49 (0) 6251 846272



Table of Contents

1.	Scope of Delivery	Fehler!	Textmarke
	nicht definiert.		
2.	Product description		2
3.	Product features		2
3.1.	Measurement principle		2
3.2.	Measurement ranges		2
3.3.	Functions		2
3.4.	Technical specifications		2
3.5.	Operational- and environmental conditions		2
3.6.	Standard and guidance		3
4.	General instructions		3
5.	Mounting and Commissioning		3
5.1.	Mounting		3
5.2.	Electrical connection		3
5.3.	Commissioning		3
6.	Calibration		3
7.	Maintenance		4
8.	Support		4

1. Scope of Delivery

- methane Sensor ZMF-201e-IR
- Mounting- and operating instructions

2. Product description

The ZMF-201e-IR is a methane sensor, designed solely for measuring the methane concentration in the ambient air, under the operating conditions mentioned below. The device is available in different measuring ranges and has an internal error monitoring. The measurement of the methane concentration takes place via the optical measuring principle NDIR (non-dispersive infrared absorption measurement). With the integrated 4...20mA output signal, the measurement signals can be evaluated by a downstream device.

The sensor unit is located in a stainless steel housing and is mounted on a diffusion opening. The cable entry is realized via cable glands. The device is powered via 12...24 V DC and can be mounted on the wall.

3. Product features

3.1. Measurement principle

The methane sensor ZMF-201e-IR measures the absolute methane concentration in the ambient air quickly and accurately with a dual-beam infrared photometer (NDIR). The measuring range is linear.

3.2. Measurement ranges

The sensor measures the methane concentration in the ambient air. The following measurement ranges are available:

0...4,4 % vol.

0...5 % vol.

0...100 % vol.

3.3. Functions

- usable as a methane sensor with 4...20mA signal output

3.4. Technical specifications

Dimensions (LxWxH): 115,6x60x27 mm

Further technical specifications are given in the product specific data sheet on our website www.fluidio.de.

3.5. Operational- and environmental conditions

- operating temperature range: -40...+60 °C
- storage temperature range: -40...+85 °C
- relative humidity: 0 to 95% (non-condensing)
- air pressure: 800...1200 mbar

3.6. Standard and guidance



The methane sensor ZMF-201e-IR is consistent with the requirements of the following European standards:

- EN 50270 (EMC Directive)
- EN 61508:2010 (part 1 to 7)
- EN 50402:2017

The declaration of conformity to the ZMF-201e-IR can be found on our website www.fluidio.de.

4. General instructions

CAUTION: Poisoning with methane (CH₄) is life threatening!



CAUTION: Under certain circumstances, the methane sensor ZMF-201e-IR cannot measure the methane concentration in the ambient air (power failure). Users and operators of plants are in charge of personnel safety and security according to applicable laws.



- Read the instructions carefully
- Keep the instructions
- Mounting, commissioning and electrical connection allowed for experts only
- Repairing is only allowed for experts only
- The mentioned international protection marking is only guaranteed when the device is built-in correctly and the electrical cables are proper connected
- Only operate the device with the correct power supply
- Modification of the device is forbidden and releases the Fluid.iO Sensor + Control GmbH & Co. KG of any guarantee and liability

5. Mounting and Commissioning

5.1. Mounting

The ZMF-201e-IR has to be mounted on a solid, flat and dry wall. The ambient conditions must be adhered.

When mounting outside, a protection against direct weather influences is necessary.

The device must be installed protected against splash water and condensate.

5.2. Electrical connection

Cable connection

White	V+ (12...24 V)
Brown	GND
Green	Output (4...20 mA)

5.3. Commissioning

Since the methane sensor ZMF-201e-IR is a sensitive measuring device, an appropriately cautious handling of the device is recommended.

Ensure prior to installation and commissioning, that the environmental conditions are suitable for the use of the device.

Make sure that the methane sensor is connected correctly and that the power supply is switched on.

6. Calibration

A calibration of the device is not necessary with standard applications. An expert may perform a calibration if required. In SIL2 applications we recommend annual calibration of the sensor with a certified test gas.

7. Maintenance

Thanks to the NDIR technology, the methane sensor ZMF-201e-IR is maintenance free.

Depending on the application, a regular calibration of the device is advised.

8. Support

Telephone: +49 (0) 6251 84620

E-Mail: info@fluidio.de

**Fluid.iO Sensor + Control
GmbH & Co. KG**
Hollandsmühle 1
98544 Zella-Mehlis

Fax: +49 (0) 6251 846272

Web: www.fluidio.de

E-Mail: info@fluidio.de